


VIGOUR


Pure Lebenskraft im Bad

Montage- und Bedienanleitung


- (CZ)** Návod k instalaci a k použití
- (E)** Instrucciones de montaje y de manejo
- (F)** Instructions de montage et mode d'emploi
- (GB)** Installation and operating instructions
- (H)** Szerelési és használati utasítás
- (I)** Istruzioni di montaggio e per l'uso
- (NL)** Montagehandleiding en Gebruiksaanwijzing
- (NO)** Monterings- og bruksanvisning
- (PL)** Instrukcja montażu i obsługi
- (RU)** Руководство по монтажу и эксплуатации
- (SK)** Návod na montáž a obsluhu



DETB



DETW



DEPTB

DIN EN 806
DIN EN 1717
DIN 1988
Global Standards

i
VIGOUR

XXXX						
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

16x

1

2

> 38 °C

3

3 min.

70°C

9 62 904/00

VIGOUR GmbH
Bergholzstraße 3
D-12099 Berlin

www.vigour.de

VIGOUR

°C / °F

max. 70 °C / 158 °F

min. 60 °C / 140 °F

√3 bar / 43,5 psi

min. 1 bar / 14,5 psi

max. 10 bar / 145 psi

3 min.

max. 70 °C / 158 °F

≥ 2 x D

D

> 15 mm

> 15 mm

> 20 mm

1.

150 mm

